

<u>Part Number</u>	<u>Description</u>	<u>Called out on these Standards Pages:</u>
BBC100	Core Bolt	BBC1000
BBC600	Sleeve	BBC1000
BBC50	Nut Assembly	BBC1000

<u>Part No.</u>	<u>Description</u>	<u>Called out on these Standards Pages:</u>
BB101	Core Bolt	BB161
BB119	Sleeve	BB120
BB126	Sleeve	BB156
BB129	Sleeve	BB159
BB130	Sleeve	BB160
BB131	Sleeve	BB161
BB136	Sleeve	BB134
BB141	Core Bolt	BB140
BB142	Sleeve	BB140
BB144	Expander	<u>BN</u> 141
BB146	Expander	BB156
BB147	Expander	<u>BN</u> 145
BB164	Sleeve	BB392
BB169	Core Bolt	BB168 (Obsoleted 9/85)
BB170	Core Bolt	BB588, BB597
BB243	Sleeve	BB242
BB244	Core Bolt	BB242
BB301	Core Bolt	BB159, BB351, BB351.32, BB351.64, BB351F, BB371, BB382, BB436
BB302	Core Bolt	BB160, BB352, BB352.32, BB352.64, BB352F, BB386, BB416G, BB420G, BB477, BB515G, BB575
BB305	Core Bolt	BB167, BB363, BB375, BB432
BB306	Core Bolt	BB166, BB362
BB307	Core Bolt	BB369
BB308	Core Bolt	BB370
BB309	Core Bolt	BB365, BB368, BB445, BB517
BB310	Core Bolt	BB376
BB311	Core Bolt	BB379, BB381
BB312	Core Bolt	BB380, BB391, BB391.64, BB392, BB569
BB313	Core Bolt	BB452
BB314	Core Bolt	BB374
BB315	Core Bolt	BB134
BB316	Core Bolt	BB120, BB366

<u>Part No.</u>	<u>Description</u>	<u>Called out on these Standards Pages:</u>
BB317	Core Bolt	BB399
BB320	Sleeve	BB515G
BB321	Sleeve	BB351, BB351F, BB399, BB428, BB588, BB700
BB321.32	Sleeve	BB351.32
BB321.64	Sleeve	BB351.64
BB322	Sleeve	BB352, BB352F, BB386, BB402, BB430, BB444
BB322.32	Sleeve	BB352.32, BB444.32
BB322.64	Sleeve	BB352.64, BB444.64
BB324	Sleeve	BB354
BB332	Sleeve	BB368, BB381, BB517
BB333	Sleeve	BB166, BB167, BB362, BB363
BB335	Sleeve	BB365, BB379, BB445, BB597
BB336	Sleeve	BB366, BB380, BB391, BB596
BB336.64	Sleeve	BB391.64
BB339	Sleeve	BB369
BB340	Sleeve	BB370
BB341	Expander	BB120, BB159, BB160, BB161, BB242, BB351, BB351F, BB351.32, BB351.64, BB352, BB352F, BB352.32, BB352.64, BB362, BB363, BB365, BB366, BB368, BB371, BB374, BB375, BB376, BB379, BB380, BB381, BB382, BB386, BB428, BB430, BB432, BB436, BB518, BB596, BB700 BN126, BN130, BN134, BN137, BN155, BN157, BN163, BN356, BN359, BN360, BN360.64, BN361-428, BN372, BN372P, BN373, BN378-1032, BN384, BN387, BN514, BN516, BN518, BN521, BN530, BN533, BN540, BN545G, BN546, BN555G, BN568 BNB1100, BNB1101, BNB1102, BNB1103, BNB1104, BNB1105, BNB1106, BNB1107, BNB1114, BNB1115, BNB1119, BNB1120, BNB1121, BNB1122, BNB1123, BNB1124
BB342	Expander	BB369, BB370
BB343	Expander	<u>BN</u> 158
BB346	Expander	BB134, BB399, BB402, BB420G, BB477, BB575, <u>BN</u> 389
BB347	Expander	<u>BN</u> 390
BB348	Expander	<u>BN</u> 388

<u>Part No.</u>	<u>Description</u>	<u>Called out on these Standards Pages:</u>
BB401	Shroud	BB401
BB403	Shroud	BB403
BB405	Expander	<u>BN</u> 519LH
BB406	Expander	BB416G, BB515G
BB408	Expander	<u>BN</u> 526
BB409	Expander	<u>BN</u> 527
BB410	Expander	<u>BN</u> 528
BB411	Core Bolt	BB402
BB412	Expander	<u>BN</u> 532
BB413	Expander	<u>BN</u> 535
BB414	Expander	<u>BN</u> 537
BB415	Expander	BB140, BB391, BB391.64, BB392, BB437, BB441, BB445, BB517, BB569 BN325, BN377, BN520, BN523, BN525, BN538, BN542, BN549, BN556G, BN565 BNB1109
BB417	Sleeve	BB416G
BB418	Expander	<u>BN</u> 543
BB419	Sleeve	BB420G
BB421	Sleeve	BB518
BB422	Core Bolt	BB441, BB518
BB426	Expander	<u>BN</u> 553
BB429	Core Bolt	BB428 (Obsoleted 9/85)
BB431	Core Bolt	BB430 (Obsoleted 9/85)
BB433	Sleeve	BB432
BB434	Expander	<u>BN</u> 557
BB435	Sleeve	BB436, BB460
BB438	Sleeve	BB437, BB441
BB439	Core Bolt	BB437
BB443	Expander	BB444, BB444.32, BB444.64
BB451	Sleeve	BB452
BB453	Expander	<u>BN</u> 555

<u>Part No.</u>	<u>Description</u>	<u>Called out on these Standards Pages:</u>
BB454	Core Bolt	BB444, BB444.32, BB444.64
BB455	Expander	BB456
BB457	Core Bolt	BB456, BB596
BB458	Sleeve	BB456
BB459	Expander	BB460, BB704, BB704.64, <u>BN362</u>
BB461	Core Bolt	BB460
BB464	Sleeve	BB463
BB464.32	Sleeve	BB463.32
BB464.64	Sleeve	BB463.64
BB466	Expander	BB463, BB463.32, BB463.64 <u>BN562</u> , <u>BNB1116</u>
BB475	Bolt Assy	BB477
BB476	Sleeve	BB477
BB478	Channel	BB477
BB500	Expander	BB500 <u>BN338</u> , <u>BN338.64</u> , <u>BN1356</u> , <u>BN1360</u> , <u>BN1557</u> , <u>BN1558</u>
BB501	Sleeve	BB371, BB382
BB504	Sleeve	BB374
BB505	Sleeve	BB375
BB506	Sleeve	BB376
BB509	Sleeve	BB509
BB509.32	Sleeve	BB509.32
BB516	Expander	<u>BN536</u>
BB566	Expander	<u>BN1556G</u>
BB567	Expander	BB166, BB167, BB452, BB572, BB588, BB597 <u>BN135</u> , <u>BN357</u> , <u>BN566</u>
BB571	Sleeve	BB569
BB573	Core Bolt	BB572
BB574	Sleeve	BB572
BB576	Sleeve	BB575
BB598	Expander	<u>BN380</u>

<u>Part No.</u>	<u>Description</u>	<u>Called out on these Standards Pages:</u>
BB703	Core Bolt	BB700
BB705	Sleeve	BB704
BB705.64	Sleeve	BB704.64
BB706	Core Bolt	BB704, BB704.64

BBC50	Nut Assy	BBC1000
BBC100	Core Bolt	BBC1000
BBC600	Sleeve	BBC1000

BM100	Expander	<u>BMB</u> 1101, BNM100, BNM101
BM102	Expander	BNM102
BM104	Expander	BNM105
BM105	Expander	BNM104, BNM105, BNM106
BM106	Expander	BNM107
BM107	Expander	<u>BMB</u> 100
BM108	Expander	BNM108
BM109	Expander	BNM109
BM110	Expander	BNM110

BMB11	Bolt	BMB1101
--------------	------	---------

<u>Part No.</u>	<u>Description</u>	<u>Called out on these Standards Pages:</u>
BN125	Sleeve	BN155
BN127	Sleeve	BN157
BN128	Sleeve	BN158
BN129	Sleeve	BN126
BN131	Sleeve	BN130
BN132	Sleeve	BN384
BN133	Sleeve	BN163
BN136	Sleeve	BN135
BN138	Sleeve	BN137
BN144	Sleeve	BN145
BN146	Sleeve	BN562, BNB1116
BN326	Sleeve	BN356, BN357, BN519LH, BN542, BN1356
BN329	Sleeve	BN359, BN514, BN520, BN535
BN330	Sleeve	BN141, BN360, BN362, BN388, BN389, BN525, BN543, BN556G, BN566, BN1360, BN1556G, BN1558 BNB1100, BNB1101, BNB1102, BNB1103, BNB1104, BNB1105, BNB1114, BNB1115, BNB1119, BNB1120, BNB1121, BNB1122, BNB1123, BNB1124
BN330.64	Sleeve	BN360.64
BN331-428	Sleeve	BN361-428
BN381	Sleeve	BN380
BN501	Sleeve	BN134
BN502	Sleeve	BN372, BN372P, BN377, BN536, BN537, BN553, BN565, <u>BNB1109</u>
BN503	Sleeve	BN373
BN507	Sleeve	BN387
BN510	Sleeve	BN378
BN511	Sleeve	BN390
BN512	Sleeve	BN512
BN515	Sleeve	BN325, BN338, BN515, BN516, BN557
BN512.64	Sleeve	BN338.64
BN517	Sleeve	BN518, BN526, BN527, BN528, BN532, BN1557, <u>BNB1107</u>
BN522	Sleeve	BN521
BN524	Sleeve	BN523

Part No. Description Called out on these Standards Pages:

BN531	Sleeve	BN530
BN534	Sleeve	BN533
BN539	Sleeve	BN538
BN541	Sleeve	BN540
BN544	Sleeve	BN545G
BN547	Sleeve	BN546
BN552	Sleeve	BN549
BN554	Sleeve	BN555, BN555G
BN560	Sleeve	<u>BNB</u> 1106
BN569	Sleeve	BN568

BNG 1 Grommet BNB1107

HC43 Bolt BMB100

MB 134 Core Bolt BB463, BB463.32, BB463.64

<u>Part No.</u>	<u>Description</u>	<u>Called out on these Standards Pages:</u>
NB1100	Bolt	BNB1100
NB1101	Bolt	BNB1101
NB1102	Bolt	BNB1102
NB1103	Bolt	BNB1103
NB1104	Bolt	BNB1104
NB1105	Bolt	BNB1105
NB1106	Bolt	BNB1106
NB1109	Bolt	BNB1109
NB1114	Bolt	BNB1114
NB1115	Bolt	BNB1115
NB1116	Bolt	BNB1116
NB1117	Bolt	BNB1121
NB1119	Bolt	BNB1119
NB1120	Bolt	BNB1120
NB1122	Bolt	BNB1122
NB1123	Bolt	BNB1123
NB1124	Bolt	BNB1124

NM100	Sleeve	<u>BMB</u> 1101, BNM100, BNM105
NM101	Sleeve	<u>BMB</u> 100, BNM101, BNM102, BNM104
NM102	Sleeve	BNM106
NM103	Sleeve	BNM107, BNM109
NM104	Sleeve	BNM108
NM105	Sleeve	BNM110